

Recover from JTAG reset.

If you accidentally reset the JTAG interface by writing a 0 to PB7, you will not be able to communicate with the kit anymore.

To recover from the reset, use the LM Flash Programmer, which can be found on BlackBoard. Connect the board, start the LM Flash Programmer and go to the “other utility” pane. Select: “Tempest Class”, press “Unlock” and follow the instructions.

It might be necessary to go through the procedure twice.

Now you should be able to download and debug again.

